

Welcome to ADVANCE

Many thanks for deciding on an ADVANCE quality product, complete with Swiss engineering.

Manual

This manual is an important part of your BIPAX. We therefore advise you to carefully read it through before your first BIPAX flight.

Important Notice

Range of use

The BIPAX is a tandem passenger harness suitable for passengers from 1.55 to 2.02 meters tall.

Certification

The BIPAX including protector is certified according to EN/LTF up to 120 kg.

Product Registration

Register your BIPAX in your MyADVANCE Account on www.advance.ch/warranty, and find out promptly by Email about updates and safety-relevant information.

Have fun

We wish you much rewarding experience with your BIPAX and many wonderful hours in the air!

Disclaimer

Every pilot carries sole responsibility for all risks associated with paragliding, including injury and death. Neither the manufacturer nor the seller of paragliding equipment can guarantee the safety of the pilot or be held responsible for it.

Delivery

Before delivery every ADVANCE product has to be checked by the dealer for completeness of the delivery package.

The BIPAX delivery package contains:

- Harness
- Two Foras carabiners with «Antitwist»
- Certified Air-Foam-Hybrid protector
- Replaceable base



Features

- 1 Adjustable shoulder straps
- 2 Closure system RED / BLUE
- 3 Foras carabiners with «Antitwist»
- 4 Back stowage and separate pocket
- 5 Air-Foam-Hybrid protector
- 6 Replaceable base
- 7 Two blue webbing markings as handles for the passenger or as pull points for the launch helpers
- 8 Velcro (for a micro vario)



Get Into the Harness

Preparing the harness

Loosen the shoulder straps completely **1** and unhook the red and blue front strap loops from the carabiners. **2**

Closing the harness

Put the harness on your passenger. Put the red and blue front strap loops back in the main carabiners. **3**

i Info: Depending on preference, the carabiners including «Antitwist» can also be mounted on the front strap. For closing the harness clip the carabiners into the red and blue main loops. **4**

! Caution: Make sure that the carabiners and the other support loops are not twisted.

Adjusting the harness

Adjust the shoulder strap lengths for the passenger.



Attaching the Spreaders

Hang the BIPAX correctly in their support loops on your tandem spreaders.

Caution: Make sure the carabiners are correctly closed, and not twisted.



Exchanging Parts

Underside

The harness base can be replaced if damaged. To do this release the Velcro surround and fit the new harness base.



Protector

The Air-Foam-Hybrid BIPAX protector can be changed. It is removed via a zip in the lower back pocket.



Warranty & Service

If you register your product on your MyADVANCE-Account within ten days of purchase you can benefit from the extended ADVANCE-Warranty. This is valid for three years for deficiencies attributable to manufacturing faults. Otherwise the warranty of your country applies.

In the MyADVANCE-Account you can find all the documentation for your harness as PDF, e.g. the manual, special information, safety updates and much more. There you

can also see spare parts for your product and contact Support with any queries.

Your BIPAX should have a thorough visual check every 24 months and be regularly inspected. Detected damage requires the harness to be immediately sent to an authorised service centre. You can find out more about the worldwide ADVANCE Service Network on www.advance.ch.

Technical Data

BIPAX

Passenger height	cm	155–202
Harness weight	kg	1.8
Protector weight	g	600
Chest strap width	cm	~45
Carabiner height	cm	~46
Certification		EN 1651 / LTF 91/09, 120 kg

FABRICS

Leg strap	15 mm Polyamid TechniSangle 13,2 kN
Shoulder strap	15 mm Polyamid TechniSangle 13,2 kN
Seatshell	Nylon Oxford 210D PU3 Seunghee
Backside	Nylon Ribstop 210D / 100D Seunghee
Base	CorduraCloth Seunghee
Air-Foam Hybrid-Protector	N-Robic 100D & 25 mm Mousse 20 kg/m3
Carabiners	Foras - 23 kN AeroTec TwistLock Edelrid

Info@advance.ch
support@advance.ch

www.advance.ch
+41 33 225 70 10

advance thruun ag
utligstrasse 87
ch 8800 thruun

ADVANCE



Getting Started

ADVANCE BIPAX

Manual
Edition 1.0 / 01.07.2020